



4X200W COB LED BLINDER LIGHT



Contents

1. General information
2. Safety instructions
3. Performance trait and skill specifications
4. Digital display
5. DMX channel
6. Cleaning and maintenance

1. General information

1. Congratulations, you have just purchased one of the most reliable 4X100W COB LED Blinder Light on the market today.

2. Please read and understand the instructions in this manual carefully and thoroughly before attempting to operate this unit. These instructions contain important information regarding safety during use and maintenance.

Notice:

As part of our ongoing commitment to continuous products update, our company will keep the right to improve this products, the information in this menu may be changed in the future, the company reserve the right to change the data without any advises.

Unpacking:

- 1) Thank you for purchasing our company products. Every product has been thoroughly tested and has been shipped in perfect operating condition.
- 2) Carefully check the shipping carton for damage that may have occurred during shipping. If the carton appears to be damaged, carefully inspect your fixture for damage and be sure all accessories necessary to operate the fixture have arrived intact. In the event damage has been found or parts are missing, please contact our customer support team for further instructions.
- 3) Inside the box you should find: the LED Blinder Light, power cable and this user manual.

2. Safety instructions

Notice: To guarantee proper and consistent operation, it is important to follow the guidelines in this manual. Our company will not accept responsibility for damages resulting from the misuse of this fixture due to the disregard of the information printed in this manual.

- 1) Please check the voltage, frequency data of power supply system is suitable for the mentioned on the light. Please do avoid the different voltage between them and burn the LED Blinder Light.
- 2) Do not attempt to operate this fixture if the power cord has become damaged or frayed.
- 3) Never open this fixture while in use.
- 4) Never look directly into the light source. You risk injury to your retina, which may induce blindness.
- 5) Please be aware that damages caused by modifications to the device are not subject to Warranty.

3. Performance trait and skill specifications

1. Light source: 4PCS 200W COB LEDs (warm white)2IN1
2. Angle: adjustable
3. Channel mode: 2 / 8 /8/14DMX channel mode
4. 0-100% linear dimmer
5. Function: Built-in program and strobe effect with adjustable speed.
6. Sound controlled via built-in microphone
7. Adjustable sound sensitivity
8. LED Display, easy to control
9. Control: auto, sound active, DMX512, software (connect to computer)
10. Overheating protection
11. Voltage: 100-220V, 50 / 60hz
12. Power: 620W
13. IP rating: IP65
14. Size: 40X40X22 CM
15. Net weight: 13 KG/UNIT

4. Digital Display

<p>2CH 8CH1 8CH2 14CH</p>	<p>-> ENTER -> (save and exit) <- MODE (exit without saving)</p>			
<p>MAST SLAV</p>	<p>-> ENTER -> (save and exit) <- MODE (exit without saving)</p>			

<p style="text-align: center;">SH-</p>	<p>-> ENTER -> <- MODE (exit without saving)</p>	<p>UP/DOWN Select show mode</p>	<p style="text-align: center;">AU 0--AU10</p>	<p>-> ENTER -> (save and exit) <- MODE (exit without saving)</p>
<p style="text-align: center;">SPED</p>	<p>-> ENTER -> <- MODE (exit without saving)</p>	<p>UP/Down (change show speed)</p>	<p style="text-align: center;">SP00--SP99</p>	<p>-> ENTER -> (save and exit) <- MODE (exit without saving)</p>
<p style="text-align: center;">ON OFF</p>	<p>-> ENTER -> (save and exit) <- MODE (exit without saving)</p>			

<p>0--99</p>	<p>-> ENTER -> (save and exit) <- MODE (exit without saving)</p>			
<p>CO-</p>	<p>-> ENTER -> <- MODE (exit without saving)</p>	<p>UP/Down (change show speed)</p>	<p>C01--C14</p>	<p>-> ENTER -> (save and exit) <- MODE (exit without saving)</p>
<p>DIMM</p>	<p>-> ENTER -> <- MODE (exit without saving)</p>	<p>UP/DOWN Select show mode</p>	<p>D0--D100</p>	<p>-> ENTER -> (save and exit) <- MODE (exit without saving)</p>

STRO	-> ENTER -> <- MODE (exit without saving)	UP/Down (change show speed)	F00--F99	-> ENTER -> (save and exit) <- MODE (exit without saving)
DIMM	-> ENTER -> <- MODE (exit without saving)	UP/Down (change Value)	000-255	-> ENTER -> (save and exit) <- MODE (exit without saving)
STRO	-> ENTER -> <- MODE (exit without saving)	UP/Down (change Value)	000-255	-> ENTER -> (save and exit) <- MODE (exit without saving)
WW	-> ENTER -> <- MODE (exit without saving)	UP/Down (change Value)	000-255	-> ENTER -> (save and exit) <- MODE (exit without saving)
CW	-> ENTER -> <- MODE (exit without saving)	UP/Down (change Value)	000-255	-> ENTER -> (save and exit) <- MODE (exit without saving)

<p>LI EO LO SC HALO</p>	<p>-> ENTER -> (save and exit) <- MODE (exit without saving)</p>			
<p>AUTO BLAC HOLD</p>	<p>-> ENTER -> <- MODE (exit without saving)</p>			
<p>ON OFF</p>	<p>-> ENTER -> <- MODE (exit without</p>			

	saving)			
Disp	-> ENTER -> <- MODE (exit without saving)			
TEST (Blink)	-> ENTER -> (save and exit) <- MODE (exit without saving)			

30	-> ENTER -> (save and exit) <- MODE (exit without saving)			
V1.0	-> ENTER -> (save and exit) <- MODE (exit without saving)			

5. DMX Channel

2 DMX channel

DMX	Value	Function
2 CHANNEL MODE		
1		ww

	0--255	0 → 100%
2	CW	
	0--255	0 → 100%
8-1 CHANNEL MODE		
1	Dimmer	
	0--255	0 → 100%
2	000-007	Strobe open
	008-015	Strobe closed
	016-115	Strobe slow → fast
	116-123	Strobe open
	124-173	fast open cslow close, slow → fast
	174-181	Strobe open
	182-231	fast close cslow open, slow → fast
	232-239	Strobe open
	240-247	thunder strobe
248-255	Strobe open	
3	ww	
	0--255	0 → 100%
4	CW	
	0--255	0 → 100%
5	CTO	
	0--255	CTO
6	0-2	Open
	3-25	show1
	26-48	show2
	49-71	show3
	72-94	show4
	95-117	show5
	118-140	show6
	141-163	show7 效果 7
	164-186	show8 效果 8
	187-209	show9 效果 9
	210-232	show10 效果 10
233-255	Random 随机效果	
7	0 - 249	Effect Speed Slow → Fast
	250-255	Sound Trigger
8	LED DIMME	

	0-50	
	51-100	
	101-150	
	151-200	
	201-255	
8-2 CHANNEL MODE		
1	ww1	
	0--255	0 → 100% 暖白 1 调光
2	ww2	
	0--255	0 → 100% 暖白 2 调光
3	ww3	
	0 - 255	0 → 100% 暖白 3 调光
4	ww4	
	0 - 255	0 → 100%
5	ww1	
	0--255	0 → 100%
6	ww2	
	0--255	0 → 100%
7	ww3	
	0 - 255	0 → 100%
8	ww4	
	0 - 255	0 → 100%
14 CHANNEL MODE		
1	Dimmer	
	0--255	0 → 100%
2	000-007	Strobe open
	008-015	Strobe closed
	016-115	Strobe slow -> fast
	116-123	Strobe open
	124-173	fast open clow close, slow -> fast
	174-181	Strobe open
	182-231	fast close clow open, slow -> fast
	232-239	Strobe open
	240-247	thunder strobe
	248-255	Strobe open
3	ww1	
	0--255	0 → 100%
4	ww2	
	0--255	0 → 100%
5	ww3	

	0 - 255	0 → 100%
6	ww4	
	0 - 255	0 → 100%
7	ww1	
	0--255	0 → 100%
8	ww2	
	0--255	0 → 100%
9	ww3	
	0 - 255	0 → 100%
10	ww4	
	0 - 255	0 → 100%
11	CTO	
	0--255	CTO CTO
12		
	0-2	Open
	3-25	show1
	26-48	show2
	49-71	show3
	72-94	show4
	95-117	show5
	118-140	show6
	141-163	show7
	164-186	show8
	187-209	show9
	210-232	show10
233-255	Random	
13	0 - 249	Effect Speed Slow → Fast
	250-255	Sound Trigger
14	LED DIMME	
	0-50	
	51-100	
	101-150	
	151-200	
	201-255	

6. Cleaning and maintenance

1. It is absolutely essential that the fixture is kept clean and that dust, dirt and smoke-fluid residues must not build up on or within the fixture.

2. Regular cleaning will not only ensure the maximum light-output, but will also allow the fixture to function reliably throughout its life.
3. A soft lint-free cloth moistened with any good glass cleaning fluid is recommended, under no circumstances should alcohol or solvents be used!