

# JCV

	Pressão		Vazão	Volume de Aplicação [L/ha] para espaçamento de 50cm														Gotas
	psi	bar	L/min	4 km/h	6 km/h	8 km/h	10 km/h	12 km/h	14 km/h	16 km/h	18 km/h	20 km/h	22 km/h	24 km/h	26 km/h	28 km/h	30 km/h	
JCV - 1 Filtro Malha 50	29,0	2	0,22	67	45	34	27	22	19	17	15	13	12	11	10	10	9	MF
	58,0	4	0,32	96	64	48	38	32	27	24	21	19	17	16	15	14	13	MF
	87,0	6	0,38	114	76	57	46	38	33	29	25	23	21	19	18	16	15	MF
	145,0	10	0,50	150	100	75	60	50	43	38	33	30	27	25	23	21	20	MF
	218,0	15	0,55	165	110	83	66	55	47	41	37	33	30	28	25	24	22	MF
	247,0	17	0,60	180	120	90	72	60	51	45	40	36	33	30	28	26	24	MF
	305,0	21	0,72	216	144	108	86	72	62	54	48	43	39	36	33	31	29	MF
JCV - 1.5 Filtro Malha 50	29,0	2	0,30	90	60	45	36	30	26	23	20	18	16	15	14	13	12	MF
	58,0	4	0,43	129	86	65	52	43	37	32	29	26	23	22	20	18	17	MF
	87,0	6	0,52	156	104	78	62	52	45	39	35	31	28	26	24	22	21	MF
	145,0	10	0,66	198	132	99	79	66	57	50	44	40	36	33	30	28	26	MF
	218,0	15	0,77	231	154	116	92	77	66	58	51	46	42	39	36	33	31	MF
	247,0	17	0,82	246	164	123	98	82	70	62	55	49	45	41	38	35	33	MF
	305,0	21	0,90	270	180	135	108	90	77	68	60	54	49	45	42	39	36	MF
JCV - 2 Filtro Malha 50	29,0	2	0,45	134	89	67	54	45	38	34	30	27	24	22	21	19	18	MF
	58,0	4	0,64	192	128	96	77	64	55	48	43	38	35	32	30	27	26	MF
	87,0	6	0,76	228	152	114	91	76	65	57	51	46	41	38	35	33	30	MF
	145,0	10	1,00	300	200	150	120	100	86	75	67	60	55	50	46	43	40	MF
	218,0	15	1,13	339	226	170	136	113	97	85	75	68	62	57	52	48	45	MF
	247,0	17	1,22	366	244	183	146	122	105	92	81	73	67	61	56	52	49	MF
	305,0	21	1,42	426	284	213	170	142	122	107	95	85	77	71	66	61	57	MF
JCV - 3 Filtro Malha 50	29,0	2,0	0,61	184	123	92	74	61	53	46	41	37	34	31	28	26	25	MF
	58,0	4	0,88	264	176	132	106	88	75	66	59	53	48	44	41	38	35	MF
	87,0	6,2	1,06	318	212	159	127	106	91	80	71	64	58	53	49	45	42	MF
	145,0	10	1,34	402	268	201	161	134	115	101	89	80	72	67	62	57	54	MF
	218,0	14,5	1,57	471	314	236	188	157	135	118	105	94	86	79	72	67	63	MF
	247,0	17	1,68	504	336	252	202	168	144	126	112	101	92	84	78	72	67	MF
	305,0	20,7	1,84	552	368	276	221	184	158	138	123	110	100	92	85	79	74	MF
JCV - 4 Filtro Malha 50	29,0	2	0,87	262	175	131	105	87	75	65	58	52	48	44	40	37	37	MF
	58,0	4	1,25	375	250	188	150	125	107	94	83	75	68	63	58	54	50	MF
	87,0	6	1,51	453	302	227	181	151	129	113	101	91	82	76	70	65	60	MF
	145,0	10	1,91	573	382	287	229	191	164	143	127	115	104	96	88	82	76	MF
	218,0	15	2,22	666	444	333	266	222	190	167	148	133	121	111	102	95	89	MF
	247,0	17	2,34	702	468	351	281	234	201	176	156	140	128	117	108	100	94	MF
	305,0	21	2,54	762	508	381	305	254	218	191	169	152	139	127	117	109	102	MF
JCV - 5 Filtro Malha 50	29,0	2	1,12	335	223	168	134	112	96	84	74	67	61	56	52	48	45	MF
	58,0	4	1,60	480	320	240	192	160	137	120	107	96	87	80	74	69	64	MF
	87,0	6	1,93	579	386	290	232	193	165	145	129	116	105	97	89	83	77	MF
	145,0	10	2,44	732	488	366	293	244	209	183	163	146	133	122	113	105	98	MF
	218,0	15	2,85	855	570	428	342	285	244	214	190	171	155	143	132	122	114	MF
	247,0	17	3,22	966	644	483	386	322	276	242	215	193	176	161	149	138	129	MF
	305,0	21	3,57	1071	714	536	428	357	306	268	238	214	195	179	165	153	143	MF
JCV - 6 Filtro Malha 50	29,0	2	1,47	440	293	220	176	147	126	110	98	88	80	73	68	63	59	MF
	58,0	4	2,10	630	420	315	252	210	180	158	140	126	115	105	97	90	84	MF
	87,0	6	2,40	720	480	360	288	240	206	180	160	144	131	120	111	103	96	MF
	145,0	10	3,00	900	600	450	360	300	257	225	200	180	164	150	138	129	120	MF
	218,0	15	2,85	1050	700	525	420	350	300	263	233	210	191	175	162	150	140	MF
	247,0	17	3,22	1200	800	600	480	400	343	300	267	240	218	200	185	171	160	MF
	305,0	21	3,57	1500	1000	750	600	500	429	375	333	300	273	250	231	214	200	MF

Espaçamento entre os bicos (cm)	20	25	30	35	40	45	50	55	60	65	70
Fator de conversão	2,50	2,00	1,67	1,43	1,25	1,11	1,00	0,91	0,83	0,77	0,71

Tabela de conversão do Volume de Aplicação para diferentes espaçamentos dos bicos.  
Multiplicar o valor da tabela do volume em L/ha pelo fator de conversão acima.

