LED PAR LIGHT = 60PCS LED USE MANUAL

> Attention

- 1. Please read these operating instructions carefully to familiarize you with basic operations of this unit BEFORE USE.
- 2. Without permitted, it is prohibited to spread the contents of this manual to others.
- 3. This manual is only to provide related information, and the contents of this manual will be changed at any time without notice.
- 4. Unless the instructions have already stated, please do not freely modified the unit.

Safety Tips:

- 1. Before installation and maintenance, please confirm the power is.

 Make sure that the ventilation around the unit is good.
- 2. The lighting is designed for indoor demonstration, please do not use this product in a wet environment for long-term.
- 3. The use and maintenance of this unit should avoid contact with water. When using it outdoor, please take waterproofing measures.
- 4. Personnel, who to take the installation, operation and maintenance, must be familiar with the lighting performance. Most of the damage is resulted from unfamiliar with its performance.
- Please do not face up to the luminous unit for a long time, so as not to cause discomfort to your eyes.

Please often wipe the unit with a clean cloth.

Packing list

While receiving the product, please take carefully and check whether it was been destroyed on conveyance. After that, check the following parts.

- 1 x Light Unit
- 1 x User Manual 2.

> LED DISPLAY FUNCTION

ITEM	DISPLAY	FUNCTION
11 <u>EM</u> 1	d0001	Address code, (001-512) B, C add and subtract address code date
2	P000	Colorful hop (00—255) B、C key change hop speed
3′	L000	Colorful gradual (00—255) B. C key change gradual speed
4	E000	Colorful pulse change (00—255) B、C key change pulse speed
5	sound	Colorful sound control
6	r000	Red (000—255) B、C key revise brightness
7	g000	Green (000—255) B、C key revise brightness
8	b000	Blue (000—255) B. C key revise brightness
9	F000	Strobe (000—255) B、C key revise strobe

> DMX512

Channel	Function	Description
CH1	Sum dimmer	R、G、B sum dimmer, linear dimmer, from dark to bright
CH2	R dimmer	R dimmer, linear dimmer, from dark to bright
CH3	G dimmer	G dimmer, linear dimmer, from dark to bright
CH4	B dimmer	B dimmer, linear dimmer, from dark to bright
CH5	Function choose	0—50: strobe and linear dimmer,51——100: hop, 101—150: gradual, 151—200: pulse change, 201—255: sound control
CH6	Function speed	Function 5CH, speed from slow to fast

Current regulation

ITEM	DISPLAY	FUNCTION
1	rL00	Red current (00—99) B. C key revise current limiting size, date increase current decrease
2	gL00	Green current (00—99) B. C key revise current limiting size, date increase current decrease
3	bL00	Blue current (00—99) B. C key revise current limiting size, date increase current decrease