## LED Stage Lighting Operating Manual



# OL-P SLIM 18X15W LED PAR LIGHT ■ RGBWA 5IN1



Please read manual carefully before use.

Thank you so much to choose this product; it is adopting the most advanced lamps, which is called LED lamps. It conquers a lot of disadvantages such as power wasting, short using life, high temperature, etc. It has advantages of power saving, long life (it can reach 60,000.00 hours in general circs), high brightness, fresh colors...It is the best stage illuminating and various effect decorative products.

#### DMX MODE


#### 9 Channels Mode (A001)

CH	Function	Instruction		
CH1	Dimmer	R. G. B. W. Y dimmer : from dark to bright		
CH2	R dimmer	R dimmer : from dark to bright		
CH3	G dimmer	G dimmer: from dark to bright		
CH4	B dimmer	B dimmer : from dark to bright		
CH5	W dimmer	W dimmer: from dark to bright		
CH6	Y dimmer	Y dimmer: from dark to bright		
CH7	Strobe	R、G、B、W 、Y strobe: slow to fast		
	Function choice	0~50: DMX 8CH Control.		
		51~100: Different Colors Output		
		101~150: Colors Jump Change.		
CH8		151~200: Colors Gradate.		
		201~250: Colors Pulse Change.		
		251~255: Sound-Active		
СН9	Function speed Speed function, from slow to fast			

#### 5 Channels Mode (d001)

СН	Function	Instruction	
CH1	R Dimmer	Red Dimmer- Dark to Bright	
CH2	G Dimmer	Green Dimmer- Dark to Bright	
CH3	B Dimmer	Blue Dimmer- Dark to Bright	
CH4	W Dimmer	White Dimmer- Dark to Bright	
CH5	Y Dimmer	Amber- Dark to Bright	

### F KEYS INSTRUCTION



#### **DIGITAL SHOW FUNCTION FORM**

No	Show	Function	Instruction
1	d001	DMX Address (1~512)	DMX-512 address set, 5 Channels mode
2	A001	DMX Address (1~512)	DMX-512 address set, 9 Channels mode
3	r255	Red (0~255)	UP、DOWN Change brightness
4	G255	Green (000~255)	UP、DOWN Change brightness
5	b255	Blue (000~255)	UP、DOWN Change brightness
6	U255	White (000~255)	UP、DOWN Change brightness
7	Y255	yellow (0~255)	UP、DOWN Change brightness
8	FH99	Strobe flash (01~99)	UP、DOWN Change the speed
9	CL01	Different Colors Output (01~08)	UP、DOWN Change brightness
10	CC99	Colors Jump Change (01~99)	UP、DOWN Change the speed
11	DE99	Colors Gradate (01~99)	UP DOWN Change the speed
12	CP99	Colors Pulse Change (01~99)	UP、DOWN Change the speed
13	SU01	Colors sound-Active (01~09)	UP、DOWN Change the effects

#### Technical:

Voltage: AC90-240V 50/60HZ

Light source: 18PCS\*15W RGBWA 5IN1 LED

Color: Red, Green, Blue, White, Amber, Ultraviolet

Channel: 9CH/5CH

Operation: DMX512, Auto, Sound, Master-slave