
200W COB warm/cold white 2 in 1



USER MANUAL

Please read this manual carefully before use!

Thank you for purchasing this product.

To optimize the performance of this product prior to use, please read these operating instructions carefully to familiar series yourself with the basic operation of this unit.

Please keep the manual in safe place for future reference.

This unit has been tested at our factory before being shipped to you, there is no assembly required.

Please take and put carefully once received this product.

Please check cautiously that whether the product was damaged or not during the transportation.

Checking Parts

Please check if the following parts are included:

- 1 x LED Light
- 1 x Power cable
- 1 x User manual

Installation







ATTENTION:
DANGER OF LIFE! RISKOF FIRE!
RISK OF SHORT CIRCUIT!

- 1. Please check the voltage whether is the same with the one showed on the equipment or not.
- 2. It must ask for the technical person and set the light safety when installation. And let the light beam at the suitable angle.
- 3. When install this equipment please make sure there's no flammable surfaces (decorated things, etc) within at least 2.5M and maintain minimum distance of 0.5M from the equipment to the walls.
- 4. Please make sure that there's no other equipment or decorating materials obstructed the exhaust fan and the vent-pipe.
- 5. Products should be install immobility
- 6. In case of safety, it's very important that to connect the earth with line.

Attention







ATTENTION: DANGER OF LIFE! RISKOF FIRE! RISK OF SHORT CIRCUIT!

- 1. Please do not open the bottom cover yourself without permission. Operate it accord the user manual. Call the technician when the machine breaks down.
- 2. Please do not see the led beam directly to avoid any damage.
- 3. This unit can be use in the outdoor with waterproof IP65.
- 4. Set the light immobility and try to avoid strong shake or hit.
- 5. Prevent dust into the equipment to avoid problems.
- 6. Please keep that there's no other equipment or decorating materials obstructed the exhaust fan and the vent-pipe when the equipment was working.
- 7. Before connect power, check the plug is immobility or not, power line should be connect well.
- 8. Please do not open or close the equipment frequently that's to avoid any affect to the life span of the led, and try the best to avoid the long time working.
- 9. Don't touch the light or draw the power line when your hand was wet. And do not pull the electronic power line.
- 10. Maintain the distance at least 3M above from the equipment to the object.
- 11. This equipment does not have any parts can repair for the users, please do not open the equipment.
- 12. When the led became dim or damaged please contact the dealer timely.
- 13. When you want to retransfer the products, you'd better use the original package to shockproof.

KEYS INSTRUCTION



DIGITAL SHOW FUNCTION FORM

No	Instruction		
A001~A512	DMX console mode 1, UP/DOWN to choose dmx value		
d001~d512	DMX console mode 2, UP/DOWN to choose dmx value		
r000~r255	Cold white dimmer from dark to bright		
G000~G255	warm white dimmer from dark to bright		
FH01∼FH99	Strobe, UP/DOWN to adjust speed. The larger the value, the faster		
CL01~CL03	Select color, UP/DOWN to choose color		
CC01~CC99	Jump, UP/DOWN to adjust speed, and the larger the value, the faster		
DE01~dE99	Gradient, UP/DOWN to adjust speed, the larger the value, the faster		
CP01~CP99	Pulse change: UP/DOWN to adjust speed		
SU01~SU02	Sound function, UP/DOWN to adjust sound function		

DMX MODE

D001 Mode

Channel	value	Instruction
CH1	0-255	Total dimming
CH2	0	No stroboscopic
	1-255	Strobe slow to fast
СНЗ	0	Dimming mode (no self-propelled effect)
	1-62	Color selection (color controlled by CH4)
	63-124	Jump (speed controlled by CH4)
	125-186	Gradient (speed controlled by CH4)
	187-249	Pulse change (speed controlled by CH4)

	250-255	Voice control mode (controlled by CH4)
CH4	0-255	Effect speed
0115	0	Cold white light off
CH5	1-255	Cold white from dark to bright
СН6	0	Warm white light off
	1-255	Warm white from dark to bright

A001 Mode:

Channel	value	Instruction
CH1	0-255	Total dimming
CH2	0	Cold white light off
	1-255	Cold white from dark to bright
СНЗ	0	Warm white light off
	1-255	Warm white from dark to bright
CH4	0	No stroboscopic
	1-255	Strobe from slow to fast
CH5	0	Dimming mode (no self-propelled effect)
	1-62	Color selection (color controlled by ch6)
	63-124	Jump (speed controlled by ch6)
	125-186	Gradient (speed controlled by ch6)
	187-249	Pulse change (speed controlled by ch6)
	250-255	Voice control mode (controlled by ch6)
CH6	0-255	Effect speed

When the DMX signal is received, the first decimal point of the nixie tube will flash, otherwise it will not be received.

M/S function

Two or more identical lamps are connected by 3-core signal wires. Any one is set as the host [color selection / gradient / pulse change / jump change / voice control / manual dimming], and other lamps are set as A001 or D001

Function Feature:

Voltage:	110-240V	
Power:	200W	
Light source:	1*200W warm/cold white 2 in 1	
Channel:	6CH	
Function:	Digital displayer	
Control mothed:	Sound control, Automatic, Strobe, Master & slave	

5. Function Feature:

Easy Operation ,Humanity Design , Dimming without strobe or shake.

Can use for record Video, photograph or television (broadcast) station etc. occasion.

Maintenance

Maintenance should be performed every 15-day period, by using a sponge which is dipped with alcohol, rather than wet cloth or other chemical liquid, to clean the led.

Always disconnect from the mains when the device is not in use or before cleaning it.

Warning

Power must be disconnected before maintenance or repair. Do not look at the light source directly

To prevent or reduce the risk of electrical shock or fire. do not expose this unit—to high temperature/rain or moisture.

Note

Don't separate device and repair them by yourself, otherwise no good repair service will be supplied.

Declaration

This device has left our premises in absolutely perfect condition. In order to maintain this condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes written in this user manual.

We cannot be made liable for damages caused by incorrect installations and unskilled operation!

Thank you very much for reading!