

6in1 Indoor LED Par Light

One, the display panel.

- 1: boot and press MANU to enter the main menu, press UP or DOWN to select menu, press ENTER to determine.
- 2: D001 flashing for DMX512 is not connected, no flicker for DMX512 connection.



MANU UP DOWN ENTER

A001	→	A512	→	10CH模式
Au01	→	Au25	→	Color selection
FF00	→	FF99	→	jump
EE00	→	EE99	→	demo mode
CC00	→	CC99	→	Pulse change
Soud	→	Soud	→	Music model
Sund	→	Sund	→	Music mode2
RGBWY-000	→	255	→	RGBWYU-OPEN

Two, channel table

6CH	CH	d001	10CH	CH	A001
CH1	0	red 00-255	CH1	0-255	dimming
	1-255			red 00-255	
CH2	0	green 00-255	CH2	1-255	green 00-255
	1-255			green 00-255	
CH3	0	blue 00-255	CH3	0	blue 00-255
	1-255			blue 00-255	
CH4	0	white00-255	CH4	1-255	white00-255
	1-255			white00-255	
CH5	0	yellow00-255	CH5	0	yellow00-255
	1-255			yellow00-255	
CH6	0	purple00-255	CH6	1-255	purple00-255
	1-255			purple00-255	
			CH7	0	purple00-255
			CH7	1-255	
			CH8	Stroboscopic	
			CH9	0-49	OPEN DMX
				50-99	jump
				100-149	demo mode
				150-199	Pulse change
				200-249	Color respiration change
			250-255	Music mode2	
			CH10	speed	

Four, technical parameters

- The power of1, DC14V/50W/120W.
- The power of2, DC24V/60W/120W.
- The light source, 36W/108W/180W LED.

