



PAR LED

18*12W 4IN1

ONE-184N1

Thank you so much to choose this product; it is adopting the most advanced lamps, which is called LED lamps. It conquers a lot of disadvantages such as power wasting, short using life, high temperature, etc. It has advantages of power saving, long life (it can reach 60,000.00 hours in general circs), high brightness, fresh colors...It is the best stage illuminating and various effect decorative products.

Security:

1. Make sure the user voltage cannot be higher or lower than the regulated value of the user manual.
2. Please take more attention while installing the fixtures. Avoid touching exposed AC cord, or will cause a deadly accident.
3. When installing the fixtures, make sure the fixtures are not exposed in an extremely hot, humid or dusty environment. Make sure the distance between the fixture and the lighted object is not less than 0.5 meters. Make sure there is no combustible or explosive object around 0.5 meters.

DMX512Control : 4Channel Model(A001)

4CH	Channel value	d001describe
CH1	0	R Close
	1-255	R open
CH2	0	G Close
	1-255	G open
CH3	0	B Close
	1-255	B open
CH4	0	W Close
	1-255	W open

8CH	Channel value	A001describe
CH1	0-255	Total dimming
CH2	0	R Close
	1-255	R open
CH3	0	G Close
	1-255	G open
CH4	0	B Close
	1-255	B open
CH5	0	W Close

	1-255	W open
CH6	0-255	Stroboscopic slow to fast
CH7	0-50	open DMX
	51-100	Program color selection
	101-150	Jump
	151-200	Gradual change
	201-250	Pulse change
	251-255	Voice control
CH8	0-255	Speed (color, voice)

No	Show	Function	Instruction
1	d001	DMX Address (1~512)	DMX-512 address set, 4 Channels mode
2	A001	DMX Address (1~512)	DMX-512 address set, 8 Channels mode
3	r255	Red (000~255)	UP、DOWN Change brightness
4	G255	Green (000~255)	UP、DOWN Change brightness
5	b255	Blue (000~255)	UP、DOWN Change brightness
6	W255	White (000~255)	UP、DOWN Change brightness
7	FH99	Strobe flash (01~99)	UP、DOWN Change the speed
8	CL01	Different Colors Output (01~08)	UP、DOWN Change brightness
9	CC99	Colors Jump Change (01~99)	UP、DOWN Change the speed
10	DE99	Colors Gradate (01~99)	UP、DOWN Change the speed
11	CP99	Colors Pulse Change (01~99)	UP、DOWN Change the speed
12	SU01	Colors sound-Active (01~09)	UP、DOWN Change the effects

Technical:

Voltage: AC110-220V 50/60HZ

Power supply: 180W

Light source: 12W*18PCS

Color: R,G,B,W

Channel:4/8CH

Operation: DMX512, Auto, Sound, Master-slave

Package: 20PCS/CARTON