

PAR LED 60*3W RGB ONE-603N1

Thank you so much to choose this product; it is adopting the most advanced lamps, which is called LED lamps. It conquers a lot of disadvantages such as power wasting, short using life, high temperature, etc. It has advantages of power saving, long life (it can reach 60,000.00 hours in general circs), high brightness, fresh colors...It is the best stage illuminating and various effect decorative products

Security:

- 1.Make sure the user voltage cannot higher or lower than the regulate value of the user manual.
- Please take more attention while installing the fixtures. Avoid touching exposed AC cord, or will cause deadly accident.
- 3. When installing the fixtures, make sure the fixtures are not exposed in extremely hot, humid or dusty environment. Make sure the distance between the fixture and the lighted object is not less than 0.5 meter. Make sure there is no combustible or explosive object around 0.5 meters.

DMX512Control: 3 Channel Model(A001)

3 Channel	Channel value	d001describe
CH1	0	R Close
	1-255	R Open
CH2	0	G Close
	1-255	G Open
CH3	0	B Close
	1-255	B Open

DMX512Control: 7 Channel Model(A001)

7 Channel	Channel value	d001describe
CH1	0-255	Total dimming
CH2	0	R Close
	1-255	R Open
CH3	0	G Close
	1-255	G Open
CH4	0	B Close
	1-255	B Open

CH5	0-9	No Stroboscopic
	10-255	Stroboscopic slow to fast
СН6	0-50	open DMX
	51-100	Program color selection
	101-150	Jump change
	151-200	Gradual change
	201-250	Pulse change
	251-255	Voice control
CH7	0-255	Speed

No	Show	Function	Instruction
1	d001	DMX Address (1~512)	DMX-512 address set, 3 Channels mode
2	A001	DMX Address (1~512)	DMX-512 address set, 7 Channels mode
3	r255	Red (000~255)	UP, DOWN Change brightness
4	G255	Green (000~255)	UP, DOWN Change brightness
5	b255	Blue (000~255)	UP, DOWN Change brightness
6	U255	White (000~255)	UP, DOWN Change brightness
7	Y255	yellow (0~255)	UP、DOWN Change brightness
8	FH99	Strobe flash (01~99)	UP, DOWN Change the speed
9	CL01	Different Colors Output (01~08)	UP、DOWN Change brightness
10	CC99	Colors Jump Change (01~99)	UP, DOWN Change the speed
11	DE99	Colors Gradate (01~99)	UP, DOWN Change the speed
12	CP99	Colors Pulse Change (01~99)	UP, DOWN Change the speed
13	SU01	Colors sound-Active (01~09)	UP, DOWN Change the effects

Technical:

Voltage: AC110-220V 50/60HZ

Power supply: 180W

Light source: 3W*60PCS

Color: R,G,B

Channel:7/3CH

Operation: DMX512, Auto, Sound, Master-slave

Package: 20PCS/CARTON