

150W Waterproof COB Light



KEYS INSTRUCTION



⊙ ⊙ ⊙ ⊙
MENU UP DOWN ENTER

☞ KEYS INSTRUCTION

| Display | Function description |
|---------|--|
| A001 | 4 channel address code, (001—512) B, C key to add and subtract address code values |
| d001 | 2 channel address code, (001—512) B, C key to add and subtract address |
| C255 | white dimmer(000-255) |
| U255 | Warm white dimmer(000-255) |
| F000 | strobe from slow to fast (000-255) |
| E00 | temperature |

☞ DMX MODE

4CH

| CH | Value | Function |
|-----|--------------------|--|
| CH1 | Tuned light | Total dimmer, from dark to bright |
| CH2 | White dimmer | White dimmer, from dark to bright |
| CH3 | Warm dimmer | Warm White dimmer, from dark to bright |
| CH4 | Total stroboscopic | Total strobe, from slow to fast |

2CH

| CH | Value | Function |
|-----|--------------|--|
| CH1 | White dimmer | White dimmer, from dark to bright |
| CH2 | Warm dimmer | Warm White dimmer, from dark to bright |

☞ Technical Reference:

Voltage: AC110-220V 50-60HZ

Power: 150W

Light source: white and warm white 2in1 150w cob

DMX Channels: 2/4 channel combination optional