








AI Theta Audio







1


A





















**B**





**2**







2



Internet




**UniFi Gateway
Console**




Switch






3







If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).

