



PRODUCT: SNOW MACHINE  
MODEL: H-S04

# USER MANUAL



VERSION 2.0

# 1. PRECAUTIONS

The 11500w snow Machine is designed and constructed so that it can be used in a safe manner. Specifically, this refers to the usage, situations, and prescriptions for the device as described in this documentation. must be installed by a qualified professional. All maintenance must be carried out by a qualified electrician. It is the responsibility of all electrician to use the 11500w snow Machine to read and follow the instructions in this manual.

## GENERAL SAFETY RULES

- Keep this device dry.
- Always connect to a grounded circuit to avoid risk of electrocution.
- Before connecting machine to power, always check voltage indicate on machine
- match to your local AC voltage. Do not use the machine if AC power voltage does not match.
- Disconnect the machine from AC power before servicing and when not in use.
- This product is for indoor use only! Do not expose to rain or moisture. If fluid is spilled, disconnect AC power and clean with a damp cloth. If fluid is spilled onto electronic parts, immediately unplug the machine.
- No user serviceable and modifiable parts inside. Never try to repair this product, an unauthorized technician may cause damage or malfunction to the machine.
- For adult use only. Never leave the machine running unattended.
- Installed the machine in a well-ventilated area. Provide at least 50 cm space around the machine.
- Never add flammable liquid of any kind to the machine.
- Make sure there are no flammable materials close to the machine while operating.
- Only use MOKA SFX fluid. Other fluid may lead to heater clog and malfunction.
- If the machine fails to work, unplug the machine and stop operation immediately.
- Before transporting the machine, make sure the fluid tank is completely drained.
- Snow fluid may present health risks if swallowed. Do not drink snow fluid. Store it securely. In case of eye contact or if fluid is swallowed, immediately look for medical advice.

## 2. TECHNICAL DATA

Product Name	1500w Big Snow Machine
Maximum flow rate	400 ml/min
Control Method	Manual,DMX512 and Remote
DMX Connectors	3/5-pin XLR
Oil Tank Capacity	20 Liters
Voltage Input (Vac)	100-120V or 200- 240 Vac
Voltage Frequency	50 or 60 Hz
Fuse	10A
DMX Channel	2
Power Consumption (Vac)	11500w
Consumable (s)	Snow Fluid
Fluid Consumption (L/H)	80 minutes 20L
The maximum height of the jet	about 8 meters
Product Size	61/56/65cm
Packing Size	61/56/54cm
N.W	34.1 kg
G.W	36.5kg
Snow volume	Adjustable
Snow speed	Adjustable

## 3. Button function description

Menu: turn the page

Address code	001-512	
Eglish	Chines	
Work	0-255 (set working time)	
Stop	0-255 (Intervals time)	
Manual	Volume (0-99)	snowflake volume setting
	Fan (0-99)	"0"close "1-99" work

+ -- – Digital plus, in standby state without dmx signal Press '+' to work regularly and quantitatively Press '+' to stop

"-"–Number minus press '-' to spray snowflakes Press '-' to stop

ENTER

Ready

## 4. Remote control function

A	spray snowflakes
B	off
C	snowflakes plus
D	snowflake reduction

## 5. DMX512 CHANNEL TABLE

### 2 CHANNEL

Channel 1	fan adjustment, air volume from small to large
Channel 2	snowflake adjustment, snowflakes from small to large

## 6. FEATURES

- Using a 20L large oil pot, no need to refuel in the middle of use
- With oil level display lighting, it is convenient to check consumables during use
- There is a 10-meter air duct between the nozzle and the machine, which is convenient for hanging without the need for high-altitude consumables
- The machine comes with an air box that can be waterproof for a short time when used outdoors
- Support LCD control, remote control, DMX512 control

## 7. TROUBLESHOOTING

Always contact our company if any malfunctions or errors occur that cannot be solved with the instructions as described in this manual.